Neowoy[•]有方

GNSS-DEMO-V1.0 User Guide

Issue 1.0

Date 2018-05-11

Neoway Product Document

Copyright © Neoway Technology Co., Ltd 2018. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Neoway Technology Co., Ltd.

Neowoy 有方 is the trademark of Neoway Technology Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

This document provides guide for users to use G6/G7.

This document is intended for system engineers (SEs), development engineers, and test engineers.

THIS GUIDE PROVIDES INSTRUCTIONS FOR CUSTOMERS TO DESIGN THEIR APPLICATIONS. PLEASE FOLLOW THE RULES AND PARAMETERS IN THIS GUIDE TO DESIGN AND COMMISSION. NEOWAY WILL NOT TAKE ANY RESPONSIBILITY OF BODILY HURT OR ASSET LOSE CAUSED BY IMPROPER OPERATIONS.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE DUE TO PRODUCT VERSION UPDATE OR OTHER REASONS.

EVERY EFFORT HAS BEEN MADE IN PREPARATION OF THIS DOCUMENT TO ENSURE ACCURACY OF THE CONTENTS, BUT ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS DOCUMENT DO NOT CONSTITUTE A WARRANTY OF ANY KIND, EXPRESS OR IMPLIED.

Neoway provides customers complete technical support. If you have any question, please contact your account manager or email to the following email addresses:

Sales@neoway.com

Support@neoway.com

Website: http://www.neoway.com

Contents

1 Board Functions	2
1.1 Top View	. 2
1.2 Interfaces	. 2
1.2.1 Power and Communication Interface	. 2
1.2.2 Extended Interfaces	. 2
1.2.3 Antenna Interface	. 2
1.3 Recommended Antenna Indicators	. 2
2 Commissioning	4
2.1 Power Supply	. 4
2.1.1 5V/12V Adapter	. 4
2.1.2 Micro-USB Cable	. 4
2.2 Installing USB Driver	. 5
3 TD Monitor	7
3.1 Overview	. 7
3.2 How to Use TD Monitor	. 8
3.3 Check Work Mode	10

About This Document

Scope

This document is applicable to G6 and G7..

It provides readers guide for how to use GNSS-DEMO-V1.0, the EVB of G6 and G7.

Audience

This document is intended for system engineers (SEs), development engineers, and test engineers.

Change History

Issue	Date	Change	Changed By
1.0	2018-05	Initial draft	Zhuo Jianzheng

Conventions

Symbol	Indication
Warning	This warning symbol means danger. You are in a situation that could cause fatal device damage or even bodily damage.
Caution	Means reader be careful. In this situation, you might perform an action that could result in module or product damages.
Note	Means note or tips for readers to use the module

1 Board Functions

G6 and G7 are high-performance and highly-integrated GNSS modules that support dual modes of BDS B1/GPS L1/GLONASS L1. These two modules combine baseband and RF on one chipset, which integrates DC-DC, LDO, power management, POR, RF processor, GNSS digital processor, 32-bit RISC CPU, RAM, FLASH, Watchdog, Timer, RTC, and short circuit protection circuit.

GNSS-DEMO-V1.0 is an EVB that Neoway designed to test G6 and G7 modules. It can help developers set up a test platform conveniently to evaluate G6 and G7 modules.

1.1 Top View



Figure 1-1 Top view of GNSS-DEMO-V1.0

The components marked in red are respectively:

- 1. USB interface
- 2. G6 module
- 3. G7 module
- 4. II2C interface and UART2 interface
- 5. UART interface (with hardware flow control)
- 6. DC input, adapter power supply

- 7. Switch for main power supply
- 8. Reset button
- 9. Interrupt button
- 10. Backup button cell
- 11. Power supply indicator
- 12. PPS indicator

1.2 Interfaces

1.2.1 Power and Communication Interface

The board is supplied 5V DC through Micro USB interface. And the switch controls the power supply to G6 or G7 module. Micro USB interface also works as the communication interface. The UART chipset starts to work once powered up.

Developers need to install PL2303 chipset driver on the computer.

1.2.2 Extended Interfaces

G6 and G7 are two GNSS modules with different package and pin allocation. The following table shows the difference of their interface resources.

	UART1	UART2	I2C interface
G6	Yes	Yes	No
G7	Yes	No	Yes

1-1Interface resources

1.2.3 Antenna Interface

By default, the antenna interface of the board is configured as active. If developers need to install passive antenna, the EVB should be rebuilt.

1.3 Recommended Antenna Indicators

		Active Antenna	Passive Antenna
Frequency Range	BDS	1561.098±2.046MHz	1561.098±2.046 MHz
	GPS	1575.42±1.023 MHz	1575.42±1.023 MHz
	GLONASS	1602.0±4 MHz	1602.0±4 MHz
Input impedance		50Ω	50Ω
Gain		≤30dB	-
Inband gain flatness		≤1.5dB	-
Noise reduction coefficient		≤1.5dB	•

Neoway ^y 有方		GNSS-DEMO-V1.0 User Guide
Input VSWR	≤1.5	≤1.5
Output VSWR	≤2	≤2
Outband rejection: 1568±30MHz	≤30dB	-
Recommended operating voltage	3.0V±0.3	-

-40~85℃

-40~85°℃

Temperature range

2 Commissioning

2.1 Power Supply

This EVB supports different types of power supply:

- 5V/12V Adapter
- USB

2.1.1 5V/12V Adapter

If an adapter is used to supply power for the board, insert it into the DC power supply interface and pull the switch to the DC side. The adapter supplies voltage ranging from 5 to 12 V.



2.1.2 Micro-USB Cable

The following figure shows a micro-USB cable, used to supply power for the module, and communicate with a computer through USB and UART. Insert the USB cable into the interface and pull the switch to the USB side.

Figure 2-2 USB cable





If the USB connection is used only for communication, pull the switch to DC.

2.2 Installing USB Driver

Before the commissioning, developers should install PL2303 driver. Perform the following steps to install it on a Windows 7 (64-bit) OS:

- **Step 1:** Check if the PL2303 driver is installed properly.
 - 1. Right-click Computer and choose Properties from the menu.
 - 2. Click Device Manager and check if the driver is installed properly.

If the driver has not been installed properly, the device is displayed as shown in the following figure.



- Step 2: Double-click PL2303_x64.exe to install the driver.
- **Step 3:** After installing the driver, check if the device is identified.

E Computer Management		
<u>File Action View H</u> elp		
🗢 🏟 🙎 🖬 👔 💀		
E Computer Management (Local	Support-PC	Actions
System roois Tack Scheduler	⊳ Dick driver	Device Manager 🔷 🔺
 Task Scheduler Task Scheduler Event Viewer Shared Folders Scal Users and Groups Performance Device Manager Storage Disk Management Services and Applications 	 Disk drives Display adapters Human Interface Devices Horizora Keyboards Keyboards Network adapters Network adapters Ports (COM & LPT) Sustain a state of the common port (COM4) Prolific USB-to-Serial Comm Port (COM4) System devices System devices Universal Serial Bus controllers 	More Actions
< >		

Step 4: Start the UART tool and select baud rate (9600 by default) and COM port. The tool will print the positioning packets.

3 TD Monitor

3.1 Overview

TD Monitor is a packet parsing tool. It can display the detailed positioning information obtained by the module, such as longitude, latitude, positioning time, satellites in view and their CN0, speed, altitude, etc.



Figure 3-1 TD Monitor GUI

- 1. Basic positioning information
- 2. CN0 of satellites in view
- 3. Height
- 4. Speed
- 5. Packets
- 6. Status configuration
- 7. UART and baudrate

3.2 How to Use TD Monitor

Step 1: Start the software, select COM port and set baudrate. The default baud rate is 9600.

H TDMonit	or V2.2.6							
Data(D)	View(V) Re	play(l	R) Too	ol(T)	Protoc	ol(P) Abo	ut(A)	
	🗙 🕜 🛛 Port	CON	V 15	- E	Baudrate	9600	•	RT
Information	L							 μ×
Longitude	0:00:0.0	0000	TTFF			Os	;	
Latitude	0:00:0.0	0000	SatsUs	ed		0+0+0)	
Altitude	0	.000	SatsInV	liew	0+0+0			
Fix State	Fix r	none	(BD+G	BD+GP+GL)				
PDOP		0.00	Directi	on		0.00	•	
HDOP		0.00	Speed		0.00Km	/h = 0.00m/s	5	
VDOP		0.00	UTC T	ime	0001-01	-01 00:00:00).	
TDOP		0.00	Local	Time	0001-01	-01 00:00:00).	
Title	Cur	I	Max		Min	Avg		
x (m)	0.0000		0		0	0		
y(m)	0.0000		0		0	0		
հ(m)	0.0000	0.0000			0	0		
II 🗖 🗖 🕹 🖓 🗖 🛛	l a aaaa		0		0	l 0		

Step 2: Click the TD-NMEA button. In the dialog box that is displayed, select the work mode and start control of the GNSS module.

The settings will not be saved after the module is reset or restarted.

🖶 TDMoni	tor V2.2.7.1(English)	_	_	_	_	_	_	_	_	_		
Data(D)	View(V) Replay(R) Tool(T)	About(A)										
	🗙 Port Disconnect 🔹 Baudrat	e 9600	TD-NMEA	SDBP UBX		E h	1. 🛠 👔	ХУ	V	h 💻 📒	🐠 - 🕟 - 🚱	- 🕕 -
Informatio	n	Ψ×	CNO				• ×	SkyPlot				μ×
Longitude	000:00:00.00000 TTFF				GPS							
Latitude	00:00:00.00000 SatsUsed	0+0	60									
Ellipsoid Heigh TI			50				8		/		- \	
Fix Stat						1			/		~ \	
PDOP	Work mode and start mode	H	audrate						/	/	/ /	
HDOP	Work mode GPS 👻	S	erial port UART1	•							ю)	
VDOP TDOP	Start mode Cold start 👻	Send	Baudrate 115200	+	Send				/			
Title	Config	F	ix Interval								/ /	
Hate	Reset Object Restore Default Se 👻	Send	interval (ms)	1000	Send				/		/	
	Start mode and reset mode		(100 ≤interval≪ interval is a mu	60000, and the ltiple of 100)								
	Start mode Cold start 👻		onfig NMEA-TXT									
h	Reset mode Hardware Reset 👻	Send	ID NMEA-	TXT-ANT 👻			• ×	Console				ά×
			On/Off Off	-	Send			Binary@Te	ext COM	AND		
1.0	GNSS Work mode	Sand										
0.3	Nork mode	Send										
0.0	MMEA output setting											
0	Sentence IJ KMC -	S 3										
Canad I	Serial port OANII	Send										
speed	(0:close 1 ^N :N is a multiple of fix	frequent)										
1.0												
0.7												
0.3		1	1	1	1	/	¢.					
0.0							set					
0	600 1200	1800						Lock	Ulear		XOR	Send
N/A	0/0 0/0 0/0	O Fix non			0%		X1	X2 X3 X4	X5		Valid:0 Fix:0	

Step 3: Developers can also set the work mode and status of the module by sending AT commands through UART.

Table 3-1	Work mode	commands
-----------	-----------	----------

	\$CCSIR,x,y*hh				
Sentence Function	Set work mode and start control				
Field	Symbol	Field Description			
1	\$CCSIR				
		x indicates work mode. The value can be			
		1: BDS			
		2: GPS			
2	х	3: BDS+GPS			
		4: GLONASS			
		5: BDS +GLONASS			
		6: GPS +GLONASS			
		0: set to 0 if users cannot determine start mode (cold, hot, or warm).			
3	У	The software will determine start mode automatically based on working mode. Start mode:			
		1: cold start			

		2: warm start
		3: hot start
4	hh	Checksum

Work Mode	Command
GPS cold start	\$CCSIR,2,1*4B
GPS warm start	\$CCSIR,2,2*48
GPS hot start	\$CCSIR,2,3*49
BDS cold start	\$CCSIR,1,1*48
BDS warm start	\$CCSIR,1,2*4B
BDS hot start	\$CCSIR,1,3*4A
GLO cold start	\$CCSIR,4,1*4D
GLO warm start	\$CCSIR,4,2*4E
GLO hot start	\$CCSIR,4,3*4F
BDS+GPS cold start	\$CCSIR,3,1*4A
BDS+GPS warm start	\$CCSIR,3,2*49
BDS+GPS hot start	\$CCSIR,3,3*48
BDS+GLO cold start	\$CCSIR,5,1*4C
BDS+GLO warm start	\$CCSIR,5,2*4F
BDS+GLO hot start	\$CCSIR,5,3*4E
GPS+GLO cold start	\$CCSIR,6,1*4F
GPS+GLO warm start	\$CCSIR,6,2*4C
GPS+GLO hot start	\$CCSIR,6,3*4D

3.3 Check Work Mode

Developers can determine the work mode based on the GSV sentence type in packets.

The packet contains GPGSV and BDGSV, indicating BDS plus GPS mode.

	COM Port Setting	
COM Port: 4	Baudrate: 9600 💌 StopBits: 1 💌	Farity: None 💌
ByteSize: 8 💌	Flow Control: No Ctrl Flow 💌	Open Port
[2018-04-19 10:36:29]\$	\$GNGSA, A. 1	A
[2018-04-19_10:36:29]\$	\$GNGSA, A, 1, , , , , , , , , , , 99. 9, 99. 9, 99. 9, 4*0F	
[2018-04-19_10:36:29]\$	GPGSV, 2, 1, 06, 02, 04, 246, , 03, 15, 055, , 23, 07, 1	14, , 24, 10, 317, , 0*61
[2018-04-19_10:36:29]\$	GPGSV, 2, 2, 06, 25, 44, 064, , 27, 39, 254, , 0*6A	
[2018-04-19_10:36:29]\$	\$BDGSV, 1, 1, 00, 0*74	
[2018-04-19_10:36:30]\$	GNRMC, 193134.00, V,,,,,,, 130712,,, N, V*12	
[2018-04-19_10:36:30]\$	GNGGA, 193134.00, , , , , 0, 00, 99.9, , , , , , *4C	
[2018-04-19_10:36:30]\$	GNGSA, A, 1, , , , , , , , , , , 99. 9, 99. 9, 99. 9, 1*0A	
[2018-04-19_10:36:30]\$	GNGSA, A, 1, , , , , , , , , , , 99. 9, 99. 9, 99. 9, 4*0F	
[2018-04-19_10:36:30]\$	GPGSV, 2, 1, 06, 02, 04, 246, , 03, 15, 055, , 23, 07, 1:	14, , 24, 10, 317, , 0*61
[2018-04-19_10:36:30]\$	\$GPGSV, 2, 2, 06, 25, 44, 064, , 27, 39, 254, , 0*6A	
[2018-04-19_10:36:30]\$	\$BDGSV, 1, 1, 00, 0*74	
[2018-04-19_10:36:31]\$	\$GNRMC, 193135.00, V, , , , , , 130712, , , N, V*13	
[2018-04-19_10:36:31]\$	\$GNGGA, 193135.00, , , , , 0, 00, 99.9, , , , , , *4D	
[2018-04-19_10:36:31]\$	\$GNGSA, A, 1, , , , , , , , , , , 99. 9, 99. 9, 99. 9, 1*0A	
[2018-04-19_10:36:31]\$	\$GNGSA, A, 1, , , , , , , , , , , 99. 9, 99. 9, 99. 9, 4*0F	
[2018-04-19_10:36:31]\$	GPGSV, 2, 1, 06, 02, 04, 246, , 03, 15, 055, , 23, 07, 1	14, , 24, 10, 317, , 0*61
[2018-04-19_10:36:31 <mark>]</mark> \$	\$GPGSV, 2, 2, 06, 25, 44, 064, , 27, 39, 254, , 0*6A	E
[2018-04-19_10:36:31]\$	\$BDGSV, 1, 1, 00, 0*74	

The packet contains GPGSV and GLGSV, indicating GLONASS plus GPS mode.

About		
COM Port Setting		
COM Port: 4 💌 Baudrate: 9600 💌 StopBits:	1 💌 Parity: None 💌	
ByteSize: 8 💌 Flow Control: No Ctrl Flow 💌	Open Port	
[2018-04-19_10:39:23]\$GLGSV, 1, 1, 00, 0*79		
[2018-04-19_10:39:24]\$GNRMC,, V,,,,,,,,, N, V*37		
[2018-04-19_10:39:24]\$GNGGA,,,,,,0,00,99.9,,,,,,*6F		
[2018-04-19_10:39:24]\$GNGSA, A, 1, , , , , , , , , , 99. 9, 99. 9, 99	. 9, 1*0A	
[2018-04-19_10:39:24]\$GNGSA, A, 1,,,,,,,,,,,,,,,,99.9,99.9,99	. 9, 2*09	
[2018-04-19_10:39:24]\$GPGSV, 1, 1, 00, 0*65		
[2018-04-19_10:39:24]\$GLGSV, 1, 1, 00, 0*79		
[2018-04-19_10:39:25]\$GNRMC,,V,,,,,,N,V*37		
[2018-04-19_10:39:25]\$GNGGA,,,,,,0,00,99.9,,,,,,*6F		
[2018-04-19_10:39:25]\$GNGSA, A, 1, , , , , , , , , 99. 9, 99. 9, 99. 9, 1*0A		
[2018-04-19_10:39:25]\$GNGSA, A, 1, , , , , , , , , , 99. 9, 99. 9, 99	. 9, 2*09	
[2018-04-19_10:39:25]\$GPGSV, 1, 1, 00, 0*65		
[2018-04-19_10:39:25]\$GLGSV, 1, 1, 00, 0*79		
[2018-04-19_10:39:26 \$GNRMC, , V, , , , , , , , N, V*37		
[2018-04-19_10:39:26 \$GNGGA,,,,,,0,00,99.9,,,,,,*6F	=	
[2018-04-19_10:39:26 \$GNGSA, A, 1, , , , , , , , , , 99. 9, 99. 9, 99	.9,1*0A	
[2018-04-19_10:39:26 \$GNGSA, A, 1, , , , , , , , , , 99. 9, 99. 9, 99	. 9, 2*09	
[2018-04-19_10:39:26]\$GPGSV, 1, 1, 00, 0*65		
[2018-04-19_10:39:26]\$GLGSV, 1, 1, 00, 0*79		